
Robot Coordinate Systems and Frames

Fanuc defines frames as:

Frames are used to describe the location and orientation of a position in three-dimensional space. The location is the X, Y, and Z directions from the origin of the reference frame. The orientation is the rotation about the X, Y, and Z axes of the reference frame. When you record a position, its location and orientation are automatically recorded as X, Y, Z, W, P, and R relative to the origin of the frame it uses as a reference.



Types of Frames


Frame	Description	Manual Reference
World	The reference frame which all positions are relative to. Origin at intersection of J1 axis with J2 axis.	Section 10.4, page 115 / page 129 (pdf)
Tool	Describes orientation and location of tool. Defined relative to center of faceplate on end of arm.	Section 10.5, page 115 / page 129 (pdf)
User	Frame taught by the programmer for defining robot movement. If not defined, World frame is used.	Section 10.7, page 135 / page 149 (pdf)
m Jog	Frame set with any location or orientation. Recommended for defining how the robot should move relative to a part which doesn't align with the world frame.	Section 10.9, page 147 / page 161 (pdf)

Frame	Description	Manual Reference
Cell	Described as being used for 3D graphics, but not documented outside of Frame overview.	


Frame Illustrations World




Tool



$\mathbf{U}\mathbf{ser}$



\mathbf{Jog}



You can set up jog frame so that the coordinates of jog frame correspond to the coordinates of the part. You can then jog along X, Y, and Z to teach the positions on the part.